

MOUNTING INSTRUCTIONS

MONTAGEHANDLEIDING

INSTRUCTION DE MONTAGE

MONTAGEANLEITUNG

ISTRUZIONI DI MONTAGGIO

MANUAL DE MONTAJE



Iveco Daily

H1/H2 L




Iveco Daily

H1/H2 L



Iveco Daily

H1/H2 L



Place bracket parallel to hinge and slide to the left as far as possible

Plaats beugel evenwijdig met scharnier en schuif zo ver mogelijk naar links

Placer le support parallèlement à la charnière et le faire glisser vers la gauche autant que possible
Platzieren Sie die Halterung parallel zum Scharnier und schieben Sie sie so weit wie möglich nach links

Posizionare la staffa parallelamente alla cerniera e far scorrere il più a sinistra possibile

Coloque el soporte paralelo a la bisagra y deslícelo hacia la izquierda tanto como sea posible

Iveco Daily

H1/H2 L



Place bracket parallel to hinge and slide to the right as far as possible


Plaats beugel evenwijdig met scharnier en schuif zo ver mogelijk naar rechts

Placer le support parallèlement à la charnière et le faire glisser vers la droite autant que possible

Platzieren Sie die Halterung parallel zum Scharnier und schieben Sie sie so weit wie möglich nach rechts



Posizionare la staffa parallelamente alla cerniera e far scorrere il più a destra possibile

Coloque el soporte paralelo a la bisagra y deslícelo hacia la derecha tanto como sea posible



Iveco Daily

H1/H2 R



Iveco Daily

H1/H2 L

